

## **Replaces Toro Greensmaster 3050 Parts**



Brush Reel Unit - R&R Special Complete Brush Reel Unit





## **Replaces Toro Greensmaster 3050 Parts**



Brush Reel Unit - R&R Special Complete Brush Reel Unit

Item <b>R&amp;R</b>	OEM		Qty	Order
No Part No.	Part No.	Description	Req	Quantity

## Standard Brush Unit

1 R150205 Complete Brush Reel Unit

3

Tech Note: R&R Brush Reel Units complete with: R101480 Brush Reel, R94-6395 Thin Bedknife, R21-6540 Solid Front Roller & R21-8450 Solid Rear Roller:

Detail Description: R&R Products Brush Reels are great for greens maintenance to clean sand and other debris left on grass surfaces after top dressing. If left on the turf, this sand and debris cause dulling and excessive wear on mowing reels and bed knives. However, with the use of R&R Brush Reels, this sand and other debris is easily swept into conventional grass baskets.<BR><BR>R&R Brush Reels are also used to stand turf up before mowing to give a cleaner, more uniform, and truer putting surface.<BR>Equipped with four replaceable polyethylene brushes mounted on a metal frame, simply replace regular mowing reels with R&R Brush Reels and adjust bed knives to clear the brushes. The height of cut should be set to the top of the grass blades or slightly below.<BR>SUGGESTED SETTING<BR>Normal Operation - Use bed knife with grass basket in place<BR>Bed Knife to Brush Reel - 1/16 in to 1/8 in clearance<BR>Brush Reel Height Adjustment - 1/32 in lower than cutting height<BR>SUGGESTED USAGE<BR>Verticutting<BR>Dew Removal<BR>Leaf Cleaning Up<BR>Thatch Prevention<BR>Prior to Overseeding<BR>Grooming Before Mowing<BR>Removal of Excessive Top Dressing: