



# Replaces Jacobsen LF-570 Parts

Traction Unit

Traction Unit



All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Jacobsen LF-570 Parts

Traction Unit

Traction Unit



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
---------	--------------	--------------	-------------	---------	----------------

10	<b>RRF10627</b>	2811255, 556418	SilverGuard Oil Filter - Hydraulic	1	
----	-----------------	--------------------	------------------------------------	---	--

## Filters

10	<b>R556418</b>	2811255, 556418	Baldwin Oil Filter - Hydraulic	1	
----	----------------	--------------------	--------------------------------	---	--

11	<b>R557772</b>	557772	Baldwin Hydraulic Filter - Return	1	
----	----------------	--------	-----------------------------------	---	--

11	<b>RRF10616</b>	557772	SilverGuard Oil Filter	1	
----	-----------------	--------	------------------------	---	--

12	<b>RX7000043081</b>	2500809, 555405	Kubota Filter - Fuel	1	
----	---------------------	--------------------	----------------------	---	--

12	<b>RRF10516</b>		SilverGuard Fuel Filter	1	
----	-----------------	--	-------------------------	---	--

13	<b>R5000919</b>	4114746, 5000919	Baldwin Air Filter Element	1	
----	-----------------	---------------------	----------------------------	---	--

13	<b>RRF10143</b>	4114746, 5000919	SilverGuard Air Filter Element	1	
----	-----------------	---------------------	--------------------------------	---	--

13	<b>RRF10195</b>	4123044, 4133820	SilverGuard Air Filter Element	1	
----	-----------------	---------------------	--------------------------------	---	--

13	<b>R4133820</b>	4123044, 4133820	Baldwin Air Filter Element	1	
----	-----------------	---------------------	----------------------------	---	--

14	<b>R108-3813</b>	4132821, 4133821	Air Filter - Inner	1	
----	------------------	---------------------	--------------------	---	--

## Belts

20	<b>RX1628297010</b>	5001284	Kubota V-Belt	1	
----	---------------------	---------	---------------	---	--

## Gauges and Controls

60	<b>RX3756063010</b>	557888	Kubota Starter	1	
----	---------------------	--------	----------------	---	--

61	<b>RX1745460010</b>	2811021	Kubota Solenoid - Stop	1	
----	---------------------	---------	------------------------	---	--

62	<b>RX1606565510</b>	5002743	Kubota Plug - Glow	3	
----	---------------------	---------	--------------------	---	--

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Jacobsen LF-570 Parts

Traction Unit

Traction Unit



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
63	<b>RX1584139010</b>	554018	Kubota Switch - Oil	1	
<b>Other Parts Available</b>					
70	<b>R500596</b>	500596	Tapered Bearing Set - Cup and Cone	2	
71	<b>R254-72</b>	313456	Cup - Bearing	2	
72	<b>R254-94</b>	313089	Tapered Bearing Cone	2	
73	<b>RX1629912360</b>	557878	Kubota Gasket - Exh Man. Na	1	
74	<b>RX1624114520</b>	557873	Kubota Gasket - Head Cover	1	
75	<b>R232-27</b>	232-27, 360111	Stem - Valve w/ Cap	1	
76	<b>R353914</b>	353914	Bolt - Wheel	4	
77	<b>R337317</b>	337317	Hydraulic Fitting - Restricted Flow	1	
77	<b>R353190</b>	353190	Orifice - Hyd Fitting Use w/R337317	1	
78	<b>R361451</b>	361451	Flat Washer 1 x 1-1/2 Hardened Thrust	0	
79	<b>R348856</b>	348856	Clamp - Muffler - 1-1/2	1	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.